

## How to Install 24” x 24” PVC Collection Tiles

The 24” x 24” PVC Ceiling Tiles, can be installed on any hard and plain surface

- ✓ The Tiles can be cut with scissors for required fitting size.
- ✓ To install the tiles on the T-bar system or suspending grids, first create a false ceiling structure on the T-bar system using Plywood, MDF, Block board etc. then just paste the tiles on the false ceiling.  
**(Applies to Drop-In ceiling tiles only).**

**To install the Glue-Up Ceiling Tiles, just follow these 4 simple steps.  
It's really quick and easy.**

**1. Prepare the surface:** Wipe off the ceiling or surface and make it smooth and even. Also remove any loose plaster, loose paint, loose wall paper etc.

**2. Draw an angle:** if the ceiling is not an exact square or rectangle, there may have some slight difference in the angle of the ceiling. So, just draw straight lines in the corner (in width and length part) and make a 90° angle as a starting point of pasting.

**3. Apply the adhesive:** Apply any good quality rubber base adhesive (we recommend Contact Cement or PowerGrab All-Purpose) on the back of the tile, and let it be dry till the solvent of adhesive evaporates. Please check the drying time on the pack of the adhesive, usually it is anywhere between 2-5 minutes. Applying the adhesive on the ceiling also will improve bonding and strength. Or mastic, a commonly used white paste that is used for installation of floor tiles and kitchen tops, only on the edges and raised crossed section of the sheet. Mastic is a fast drying adhesive, so holding it for about 3- 4 seconds should be more than enough.

We suggest applying the adhesive on the ceiling also for better bonding and strength.

**4. Place & Press:** Place the sheet in the required position (first sheet at the 90° corner) and press firmly but gently. Overlap the edges of the previous sheet and press firmly with fingertips.

Example of Overlapping the Edges / Border  
of the Ceiling Tiles at the time of Installation

